§ 147.1107

(b) Regulations: No vessel may enter or remain in this safety zone except the following: (1) An attending vessel, (2) a vessel under 100 feet in length overall not engaged in towing, or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CCGD 11-79-02, 47 FR 39679, Sept. 9, 1982; 48 FR 33263, July 21, 1983]

§147.1107 Platform GILDA safety zone.

- (a) Description: The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 34° –10'–56''N. 119° –25'–07''W.
- (b) Regulations: No vessel may enter or remain in this safety zone except for the following: (1) An attending vessel, (2) a vessel under 100 feet in length overall not engaged in towing, or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CCGD 11-79-02, 47 FR 39679, Sept. 9, 1982; 48 FR 33263, July 21, 1983]

§147.1108 Platform EDITH safety zone.

- (a) *Description:* The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 33°-35′-45″N. 118°-08′-27″W.
- (b) Regulations: No vessel may enter or remain in this safety zone except for the following: (1) An attending vessel, (2) a vessel under 100 feet in length overall not engaged in towing, or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CCGD 11-79-02, 47 FR 39679, Sept. 9, 1982; 48 FR 33263, July 21, 1983]

§147.1109 Platform HERMOSA safety zone.

- (a) Description: The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 34-27-19 N, 120-38-47 W.
- (b) Regulations: No vessel may enter or remain in this safety zone except the following: (1) An attending vessel, (2) a vessel under 100 feet in length overall not engaged in towing or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD 11-84-01, 49 FR 33015, Aug. 20, 1984]

§147.1110 Platform HARVEST safety zone.

- (a) *Description:* The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 34-28-09.5N, 120-40-46.1W.
- (b) Regulations: No vessel may enter or remain in this safety zone except for the following: (1) An attending vessel, (2) a vessel under 100 feet in length overall not engaged in towing or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD 11-84-01, 49 FR 33016, Aug. 20, 1984]

§147.1111 Platform EUREKA safety zone.

- (a) *Description:* The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 33–33–50N, 118–07–00W.
- (b) Regulations: No vessel may enter or remain in this safety zone except the following: (1) An attending vessel, (2) a vessel under 100 feet in length overall not engaged in towing or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD 11-84-01, 49 FR 33016, Aug. 20, 1984]

§147.1112 Platform HIDALGO safety zone.

- (a) *Description:* The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 34–29–42N, 120–42–08W.
- (b) Regulations: No vessel may enter or remain in this safety zone except the following: (1) An attending vessel, (2) a vessel under 100 feet in length overall not engaged in towing or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD 11-84-01, 49 FR 33016, Aug. 20, 1984]

§147.1113 Platform GAIL safety zone.

- (a) Description: The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 34° -07′-30″ N, 119° -24′-01″ W.
- (b) *Regulation:* No vessel may enter or remain in this safety zone except the following: (1) An attending vessel, (2) a

Coast Guard, DOT § 147.1116

vessel under 100 feet in length overall not engaged in towing, or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD11-87-06, 52 FR 9657, Mar. 26, 1987]

§147.1114 Platform HARMONY safety

- (a) Description: The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 34° –22'–36'' N, 120° –10'–03'' W.
- (b) Regulation: No vessel may enter or remain in this safety zone except the following: (1) an attending vessel; (2) a vessel under 100 feet in length overall not engaged in towing; or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD11-92-01, 57 FR 9055, Mar. 16, 1992]

§147.1115 Platform HERITAGE safety zone.

(a) ${\it Description:}$ The area within a line 500 meters from each point on the

structure's outer edge. The position of the center of the structure is 34° –21'–01'' N, 120° –16'–45'' W.

(b) Regulation: No vessel may enter or remain in this safety zone except the following: (1) An attending vessel; (2) a vessel under 100 feet in length overall not engaged in towing; or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD11-92-01, 57 FR 9055, Mar. 16, 1992]

§147.1116 Platform IRENE safety zone.

- (a) Description: The area within a line 500 meters from each point on the structure's outer edge. The position of the center of the structure is 34° –36'–37.5'' N, 120° –46'' W.
- (b) Regulation: No vessel may enter or remain in this safety zone except the following: (1) An attending vessel; (2) a vessel under 100 feet in length overall not engaged in towing; or (3) a vessel authorized by the Commander, Eleventh Coast Guard District.

[CGD11-92-02, 57 FR 9054, Mar. 16, 1992]